














CHAIN GUIDE CRUNA CATENA

COD. 500008600


KAWASAKI, HONDA, YAMAHA					ACERBIS PARTS SUZUKI					KTM, HUSQVARNA, HUSABERG, GASGAS, SHERCO			
													
F - (4 PCS)	H - (2 PCS)				A - (5 PCS)	H - (2 PCS)	D - (1 PCS)	E - (2 PCS)	F - (4 PCS)	G - (1 PCS)	F - (4 PCS)	(1 PCS)	(1 PCS)




Remove the original chain guide and close the link in the chain.
Rimuovere il cruna catena originale e chiudere la maglia della catena.



Place the Acerbis chain guide over the chain and secure it on the front side using the bushings (A), bolts (E) and nuts (H). Repeat the operation on the rear side using the bolt (D), washer (B) and bushing (C). Attach the chain slider using the four screws (F).
ATTENTION: Bushings (A) and (C) are different! posizionare il corpo cruna sopra la catena, fissare il cruna anteriormente tramite le boccole (A), le viti (E) e i dadi (H). Ripetere l'operazione posteriormente tramite la vite (D), la rondella (B) e labocca (C). Montare il pattino catena tramite le 4 viti (F). **ATTENZIONE:** non confondere le boccole (A) con la boccola (C).



Place the Acerbis chain guide over the chain and secure it on the front side using the bushings (A), bolts (E) and nuts (H). Repeat the operation on the rear side using the bolt (D) and bushing (A). Attach the chain slider using the four screws (F).
Posizionare il corpo cruna sopra la catena, fissare il cruna anteriormente tramite le boccole (A), le viti (E) e i dadi (H). Ripetere l'operazione posteriormente tramite la vite (D) e la boccola (A). Montare il pattino catena tramite le 4 viti (F).



Place the Acerbis chain guide over the chain and secure it on the front side using the bushing (G) as shown in figure. Then tighten it using the original screws. Attach the chain slider using the four screws (F).
Posizionare il corpo cruna sopra la catena, fissare il cruna anteriormente tramite la vite originale, inserire la boccola (G) come da indicazione e fissarla tramite viti originali. Montare il pattino catena tramite le 4 viti (F).

WARNING!

Use Acerbis' products at your own risk. Check the safety of your device before you ride. Be sure that you follow the instructions for installing the Acerbis' products. Do not ride if there is missing or damaged hardware. If this is the case, take the item immediately back to your dealer. Make sure the throttle and other controls are free every time you ride. Not following these instructions and warnings could lead to interference with the controls, loss of control, and accidents. Acerbis recommends that installation must be done by a licensed mechanic and that only Acerbis' original parts are used during installation. Acerbis makes no guarantees or representations, express or implied, regarding the fitment of its product for any particular purpose. Acerbis makes no guarantees or representations, express or implied, regarding the extent to which its products protect individuals or property from injury or death or damage.

EUROPE

ACERBIS ITALIA S.P.A.
VIA SERIO, 37
24021 ALBINO (BG)
ITALY

U.S.A.

ACERBIS U.S.A. INC.
MAIL P.O. BOX 2030
SUN VALLEY, ID 83353
SHIP 110 LINDAY CIRCLE
KETCHUM, ID 83340
U.S.A.

UNITED KINGDOM

ACERBIS U.K LTD
UNIT 2 LUTON ENTERPRISE PARK
SUNDON PARK ROAD
LUTON, BEDFORDSHIRE LU3 3GU
GREAT BRITAIN